


SUPERBOLT

Superbolt Schematic

psychoballistics



NPS PARTS



NPS EXCLUSIVE PARTS



Order schematics parts online at
www.paintballsolutions.com or call
 1-800-220-3222

Superbolt Parts List

- | | | |
|--------------------------|----------------------------------|----------------------------|
| 1. Main Body | 21. Sear Plate | 43. Pump Arm |
| 2. Feed Neck | 22. Grip Frame Screws | 44. Cocking Rod |
| 3. ASA | 23. Sear Spring | 45. Ram Plunger w/O-Ring |
| 4. Grip Frame | 24. Trigger Plate | 46. Front Block Set Screw |
| 5. Front Block | 26. 3-Way Set Screw | 47. Feed Neck Set Screw |
| 6. Delrin Bolt | 27. Actuating Rod | 48. Two-Piece Stock Barrel |
| 8. Back Block | 28. 3-Way Stem and O-Rings | |
| 9. Velocity Adjuster | 29. 3-Way O-Rings | |
| 10. Main Spring | 30. 3-Way Body | |
| 11. Hammer | 31. LPR Block Adapter | |
| A. Hammer Lug | 32. Low Pressure Regulator Valve | |
| B. Hammer Set Screws | 33. Regulator Plunger | |
| 12. Lock Nut | 34. Regulator Body | |
| 13. Gas Valve | 35. Regulator Spring | |
| 14. Cupseal | 36. Regulator Cap | |
| 15. Valve Spring | 37. Jam Nut | |
| 17. Gas Valve Stop Screw | 38. Ram Block Adapter | |
| 18. Metal Ball Detent | 39. Ram Air Adapter | |
| 19. Grip Panel Screws | 40. Ram Rod | |
| 20. Wrap Around Grip | 41. Ram Front Body | |

psychoballistics



Superbolt