



### ICON X Parts List

- |                        |                          |                         |
|------------------------|--------------------------|-------------------------|
| 1. Hammer              | 16. Multi-Use O-Ring     | 30. Drop Forward Screws |
| 2. Main Spring         | 17. Grip Frame Pin Set   | 32. Gas-Thru            |
| 3. Recoil Pad          | 18. Vertical Feed Screws | 33. Vertical ASA        |
| 4. Spring Strut        | 19. Bottomline Screws    | 34. Main Body           |
| 5. Quick Strip Pin     | 20. Grip Panel Screws    | 35. Grip Frame          |
| A. R-Clip              | 21. Grip Frame Screws    | 36. Grip Panels         |
| 6. Gas Valve           | 22. Vertical ASA Screw   | 37. Sear                |
| 7. Cupseal             | 23. Barrel               | *38. Sear Spring        |
| 8. Valve Spring        | 24. Hammer Plug          | 40. Trigger             |
| 9. Valve Gas Plug      | 25. Gas Line             |                         |
| 10. Valve Stop Pin     | 26. Low Pressure Chamber |                         |
| 11. Vertical Feed Neck | 27. Sight Rail           |                         |
| 12. Velocity Adjuster  | A. Sight Rail Screw      |                         |
| 13. Metal Ball Detent  | 28. Bolt                 |                         |
| 14. Tank Adapter       | A. Connecting Pin        |                         |
| 15. Air Filter         | C. Connecting Pin Set    |                         |
| A. Hose Fitting O-Ring | 29. Drop Forward         |                         |



\*Not Shown In Schematic